

# ENTERPRISES

Product:

## PROTECTIVE WINGS FOR JPOINT SIGHT

#### PARTS INCLUDED

- Guard wing mount
- Two (2) 6-32 x 1/2" button head cap screws
- Two (2) 6-32 x 1/4" flathead cap screws
- Two (2) 6-32 x 3/8" flathead cap screws
- Two (2) 6-32 x 1/2" flathead cap screws
- Two (2) 6-32 x 5/8" flathead cap screws

#### CAUTION:

**REMOVE MAGAZINE AND** VISUALLY CHECK CHAMBER TO ENSURE THAT FIREARM IS UNLOADED.

The JPA-GUARD accessory for the JPoint MRD sight is designed to interface with any compatible JPoint footprint to provide extra impact protection to sight.

To install directly to your existing mount or sight cut, attach the JPA-GUARD by seating the corner pegs of your existing mount into the recesses in the bottom of the JPA-GUARD. Then, attach the JPoint sight using the longer half-inch buttonhead screws included in this package.

#### PIGGYBACK SCOPE MOUNTING

The JPA-GUARD is also designed to serve as part of an optics setup with the JPoint mounted piggyback to a primary optic. To facilitate such setups, we offer the JPA-SM30/1C mount, which can replace the top strap of one of our own JP Flattop Scope Mounts. The JPA-GUARD can also mount directly atop the scope strap of our 34mm scope mount.

In such setups, tall scope turrets may require the JPoint to sit higher than a direct mounting will permit. If this is the case with your scope, you'll want to purchase a pack of our 1° shims for the JPoint (JPA-SHIM).

When installing the JPA-GUARD atop shims, install the suitable length of flathead screws included in this pack. These screws should pass through the forward two holes of the JPA-GUARD and shims to thread into the scope strap. Choose the longest screws possible that don't protrude through the bottom of the scope strap. Tension these screws down tightly to work out any looseness in the shims themselves. Then, select the suitable length of buttonhead cap screws from those included in the shims to secure the JPoint. Again, these should be the longest screws possible that don't protrude through the bottom of the scope strap.

This setup will provide a solid platform with the additional height needed to clear your turrets.

### THANKS FOR YOUR BUSINESS!